



- |  |   |
|--|---|
| <ul style="list-style-type: none"> <li><b>1</b> Trend Display Area</li> <li><b>2</b> Numerical Display Area</li> <li><b>3</b> Menu/Previous Level Button</li> <li><b>4</b> AUDIO PAUSED/OFF Button</li> <li><b>5</b> AUDIO PAUSED/OFF Indicator (yellow LED)</li> <li><b>6</b> Door Handle</li> <li><b>7</b> Docking Station Door (colored dot in center of door indicates the SDM's PO<sub>2</sub> activation status: blue if activated, orange otherwise)</li> <li><b>8</b> Enter Button</li> <li><b>9</b> Display Button</li> <li><b>10</b> AC Power/Battery Indicator (green/yellow LED)</li> <li><b>11</b> UP/DOWN Buttons</li> <li><b>12</b> ON/OFF Indicator (green LED)</li> </ul> | <ul style="list-style-type: none"> <li><b>13</b> Status Bar</li> <li><b>14</b> Speaker (on the side)</li> <li><b>15</b> Sensor Connection Port</li> <li><b>16</b> Multipurpose I/O-Port (Nurse Call &amp; Analog Output)</li> <li><b>17</b> Serial Data Port (RS-232)</li> <li><b>18</b> Network Port (LAN)</li> <li><b>19</b> Gas Bottle Slot</li> <li><b>20</b> Fan</li> <li><b>21</b> Equipotential Terminal Connector (ground)</li> <li><b>22</b> Fuse Holder</li> <li><b>23</b> AC Power Connector</li> <li><b>24</b> ON/OFF Switch</li> </ul> |
|--|---|

